



JP1 open, JP2 open : SNES controller connected
 JP1 close, JP2 open : NES controller connected
 JP1 open, JP2 close : Undefined (led blink)
 JP1 close, JP2 close : Undefined (led blink)

Pinout reference for NES controller